
F60
30
30<60
A836
Electronic immobil-
iser control unit
CS
F49
30<49
A1
General module
control unit
MZS
MER
MVRFT
VRFT
ERFT
TKFT
MZS
MER
MVR
ERBT
MZS
MER
MVR
MZS
MER
MVR
MZS
MER
MERHK
HKK
TOEHKI
VRHK
TZV
FZV
S49
System lock, pas-
senger's door
M16
Central locking
drive, fuel filler flap
S204
Rear lid release
switch (interior)
S167
Rear lid lock
switch
A194
Remote control
central locking
S47
System lock, driv-
er's door
M14
System lock, rear
passenger's side
M17
Central locking
drive, boot lid/tail-
gate
S18
Hazard warning/
central locking
switch
31L<4
31L<3
31L<4
M15
System lock, rear
driver's side
31<6
31E<2
31<6
31E<1
31E<2